

SpinFire Functions

SpinFire Ultimate uses specialized software (called *importers*) to enable you to view native 3D CAD files in nearly all the most popular file formats. (See [Importers](#) for more information.) Other importers enable you to view 2D CAD files.

The [Workspace](#) is where all the documents are viewed, changed, and saved. The [2D Document](#) and [3D Document](#) toolbars contain the commands for working with files.

When a multi-page CAD drawing is opened in SpinFire Ultimate, a separate document is created for each page—these documents comprise one *.2D* file when saved.

Similarly, when a 3D CAD model has 2D drawings associated with it, each 2D drawing results in a separate document, in addition to the model document. When saved, the model and associated documents make up a *.3D* file.

Each document in a file is represented by a tab, and can be viewed by clicking on the tab. (See [Working with Documents](#).)

Quick Links

Opening, Saving, Printing, and Exiting Documents

[Working with Documents](#)

Views

[Working with Views](#)

2D Document Dimensioning

[Working with 2D Documents](#)

[Working with 2D Markups](#)

Cross-Sectioning

[Working with Cross Sections](#)

3D Model Dimensioning

[Working with Linear Measurements](#)

[Working with Radial Measurements](#)

[Working with Angular Measurements](#)

[Working with Smart Dimensions](#)

[Working with 3D Markups](#)

Notes

[Working with Notes](#)

PMI Annotations

[Working with PMI Annotations](#)

Assemblies and Parts

[Working with Assemblies and Parts](#)